



ComboCovers Installation Instructions

Elastic with Velcro Tire Covers
with Grommets & Bungees

(patent pending)



STEP 1:

Place cover over top $\frac{3}{4}$ of each tire
before proceeding to STEP 2.



STEP 2:

Drive equipment forward until Velcro
is toward top of tire.



STEP 3:

Secure Velcro ends together.



STEP 4:

Insert "S" hooks on ends of bungee
straps into the grommets on sides of
cover on both sides of tire.

BUILD CLEANER

BUILD SMARTER

BUILD GREENER